

VISUALDSP⁺⁺™ 2.0

Assembler and Preprocessor Manual for ADSP-21xxx DSPs

Third Revision, September 2001

Part Number
82-001964-01

Analog Devices, Inc.
Digital Signal Processor Division
One Technology Way
Norwood, Mass. 02062-9106



Copyright Information

©2001 Analog Devices, Inc., ALL RIGHTS RESERVED. This document may not be reproduced in any form without prior, express written consent from Analog Devices, Inc.

Printed in the USA.

Disclaimer

Analog Devices, Inc. reserves the right to change this product without prior notice. Information furnished by Analog Devices is believed to be accurate and reliable. However, no responsibility is assumed by Analog Devices for its use; nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under the patent rights of Analog Devices, Inc.

Trademark and Service Mark Notice

The Analog Devices logo, VisualDSP, the VisualDSP logo, SHARC, and the SHARC logo are registered trademarks; VisualDSP++, the VisualDSP++ logo, CROSSCORE, the CROSSCORE logo, EZ-KIT Lite, Apex-ICE, Mountain-ICE, Summit-ICE, Trek-ICE, and The DSP Collaborative are trademarks of Analog Devices, Inc.

Microsoft and Windows are registered trademarks and Windows NT is a trademark of Microsoft Corporation.

Adobe and Acrobat are registered trademarks of Adobe Corporation.

Intel is registered trademark of Intel Corporation.

All other brand and product names are trademarks or service marks of their respective owners.

Rev. 3.0

CONTENTS

INTRODUCTION

| | |
|--|-----|
| For Additional Information About Analog Products | 1-2 |
| For DSP Technical or Customer Support | 1-2 |
| Purpose of this Manual | 1-3 |
| Intended Audience | 1-3 |
| Manual Contents Description | 1-4 |
| What's New in this Manual | 1-4 |
| Related Documents | 1-5 |
| Conventions | 1-6 |

ASSEMBLER

| | |
|--|------|
| Overview | 2-1 |
| Assembler Guide | 2-3 |
| Writing Assembly Programs | 2-3 |
| Program Content | 2-6 |
| Program Structure | 2-7 |
| Program Interfacing Requirements | 2-10 |
| Preprocessing a Program | 2-11 |
| Reading a Listing File | 2-12 |

CONTENTS

| | |
|--|------|
| Setting Assembler Options | 2-14 |
| Assembler Command-Line Reference | 2-16 |
| Assembler Command-Line Interface | 2-16 |
| Running the Assembler | 2-17 |
| Assembler Command-Line Switch Summary | 2-19 |
| Assembler Command-Line Switch Descriptions | 2-21 |
| -21[020 060 061 062 065L 160 161] | 2-21 |
| -D <i>macro</i> [= <i>def</i>] | 2-21 |
| -g | 2-21 |
| -h[elp] | 2-21 |
| -i <i>directory</i> | 2-22 |
| -l <i>filename</i> | 2-22 |
| -M | 2-23 |
| -MM | 2-23 |
| -Mo <i>filename</i> | 2-24 |
| -Mt <i>filename</i> | 2-24 |
| -o [<i>filename</i>] | 2-24 |
| -pp | 2-25 |
| -r | 2-25 |
| -sp | 2-25 |
| -v[erbose] | 2-25 |
| -version | 2-26 |
| -w | 2-26 |

| | |
|---|------|
| Assembler Syntax Reference | 2-27 |
| Assembler Keywords & Symbols | 2-27 |
| Assembler Expressions | 2-31 |
| Assembler Operators | 2-32 |
| Numeric Formats | 2-35 |
| Comment Conventions | 2-36 |
| Assembler Directives | 2-36 |
| .ALIGN, Specify an Address Alignment | 2-39 |
| INPUT_SECTION_ALIGN() Linker Instruction | 2-40 |
| .EXTERN, Refer to a Globally Available Symbol | 2-42 |
| .FILE, Override the Name of an Object File | 2-43 |
| .GLOBAL, Make a Symbol Globally Available | 2-44 |
| .LEFTMARGIN, Set the Margin Width of a Listing File | 2-45 |
| .LIST/.NOLIST, Listing Source Lines and Opcodes | 2-46 |
| .LIST_DATFILE/.NOLIST_DATFILE, Listing Data Initialization Files | 2-47 |
| .LIST_DEFTAB, Set the Default Tab Width for Listings ... | 2-48 |
| .LIST_LOCTAB, Set the Local Tab Width for Listings | 2-49 |
| .LIST_WRAPDATA/.NOLIST_WRAPDATA | 2-50 |
| .NEWPAGE, Insert a Page Break in a Listing File | 2-51 |
| .PAGELENGTH, Set the Page Length of a Listing File | 2-52 |
| .PAGEWIDTH, Set the Page Width for a Listing File | 2-53 |
| .PORT, Legacy Directive | 2-54 |
| .PRECISION, Select Floating-Point Precision | 2-55 |
| .PREVIOUS, Revert to Previously Defined Section | 2-56 |

CONTENTS

| | |
|---|------|
| .ROUND, Select Floating-Point Rounding | 2-57 |
| .SECTION, Declare a Memory Section | 2-59 |
| .SEGMENT & .ENDSEG, Legacy Directives | 2-61 |
| .TYPE, Change Default Symbol Type | 2-62 |
| .VAR, Declare a Data Variable or Buffer | 2-63 |
| .VAR and ASCII String Initialization Support | 2-65 |
| .WEAK, Support a Weak Symbol Definition and Reference | 2-67 |
| Assembler Glossary | 2-68 |

PREPROCESSOR

| | |
|---|------|
| Overview | 3-1 |
| Preprocessor Guide | 3-3 |
| Setting Preprocessor Options | 3-3 |
| Using Header Files | 3-4 |
| Writing Macros | 3-5 |
| Writing Compound Statements As Macros | 3-6 |
| Using Predefined Macros | 3-7 |
| Preprocessor Command-Line Interface | 3-9 |
| Running the Preprocessor | 3-9 |
| Preprocessor Command-Line Switch Summary | 3-11 |
| Preprocessor Command-Line Switch Descriptions | 3-12 |
| -cs! | 3-12 |
| -cs/* | 3-12 |
| -cs// | 3-12 |
| -cs{ | 3-12 |

| | |
|--|------|
| -csall | 3-12 |
| -D <i>macro</i> [= <i>def</i>] | 3-12 |
| -h[elp] | 3-13 |
| -i I <i>directory</i> | 3-13 |
| -M | 3-13 |
| -MM | 3-14 |
| -Mo <i>filename</i> | 3-15 |
| -Mt <i>filename</i> | 3-15 |
| -o [<i>filename</i>] | 3-15 |
| -v[erbose] | 3-15 |
| -version | 3-15 |
| Preprocessor Directives/Commands | 3-16 |
| #define | 3-19 |
| #elif | 3-21 |
| #else | 3-22 |
| #endif | 3-23 |
| #error | 3-24 |
| #if | 3-25 |
| #ifdef | 3-26 |
| #ifndef | 3-27 |
| #include | 3-28 |
| #line | 3-29 |
| #undef | 3-30 |
| #warning | 3-31 |

| | |
|-----------------------------------|------|
| # (String) | 3-32 |
| ## (Concatenate) | 3-33 |
| ? (Generate a Unique Label) | 3-34 |

INDEX