


- NOTES:
1. POPULATE M1-M5 WITH RUBBER FEET. SEE SHEET 2 FOR LOCATION.
 2. PLACE SERIAL NUMBER ON BOTTOM SIDE SEE SHEET 2 FOR LOCATION.
 3. PLACE BOM REV ON BOTTOM SIDE SEE SHEET 2 FOR LOCATION.
 4. BEFORE WAVE SOLDERING MASK HOLES FOR TP1-TP8.
 5. BREAK OFF STRIPS AT COMPLETION OF ASSEMBLY.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE : .XX +/- .010 .XXX +/- .005	CONTRACT NO.		 20 Cotton Road Nashua, New Hampshire 03063 (603) 883-2430 FAX (603) 882-2655
	APPROVALS	DATE	
MATERIAL	DRAWN	06/25/07	ASSEMBLY DRAWING TOP SIDE ADSP-21262 EZ-KIT LITE
FINISH	ENGINEERING		
DO NOT SCALE THIS DRAWING	MANUFACTURING		SIZE B DWG. NO. ASSMAA0174-2002-REF REV. 2.0
SCALE 1:1		SHEET 1 OF 2	