


CUT PIN 3 TO KEY CONNECTOR

SEE NOTE 2

NOTES:

1. POPULATE M1-M5 WITH RUBBER FEET. SEE SHEET 2 FOR LOCATION.
2. PLACE SERIAL NUMBER ON BOTTOM SIDE SEE SHEET 2 FOR LOCATION.
3. PLACE BOM REV ON BOTTOM SIDE SEE SHEET 2 FOR LOCATION.
4. BEFORE WAVE SOLDERING MASK HOLES FOR TP1-TP10 AND P16.
5. BREAK OFF STRIPS AT COMPLETION OF ASSEMBLY.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE : .XX +/- .010 .XXX +/- .005	CONTRACT NO.		 20 Cotton Road Nashua, New Hampshire 03063 (603) 883-2430 FAX (603) 882-2655
	APPROVALS	DATE	
MATERIAL	DRAWN	06/13/07	ASSEMBLY DRAWING TOP SIDE ADSP-BF538F EZ-KIT LITE
FINISH	CHECKED		
DO NOT SCALE THIS DRAWING	ENGINEERING		SIZE B DWG. NO. ASSMAA0203-2006-REF
	QUALITY		
	MANUFACTURING		SCALE 1 : 1
			SHEET 1 OF 2