

VISUALDSP++TM 2.0

Linker & Utilities

Manual for ADSP-21xx DSPs

Third Edition, April 2001

Part Number
82-000349-02

Analog Devices, Inc.
Digital Signal Processor Division
One Technology Way
Norwood, Mass. 02062-9106



Copyright Information

©1996–2001 Analog Devices, Inc., ALL RIGHTS RESERVED. This document may not be reproduced in any form without prior, express written consent from Analog Devices, Inc.

Printed in the USA.

Disclaimer

Analog Devices, Inc. reserves the right to change this product without prior notice. Information furnished by Analog Devices is believed to be accurate and reliable. However, no responsibility is assumed by Analog Devices for its use; nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under the patent rights of Analog Devices, Inc.

Trademark and Service Mark Notice

The Analog Devices logo, VisualDSP, SHARC, the SHARC logo, TigerSHARC, the TigerSHARC logo, and EZ-LAB are registered trademarks; VisualDSP++, the VisualDSP++ logo, VDK, Apex-ICE, Mountain-ICE, Summit-ICE, Trek-ICE, and The DSP Collaborative are trademarks of Analog Devices, Inc.

Microsoft and Windows are registered trademarks and Windows NT is a trademark of Microsoft Corporation.

Adobe and Acrobat are registered trademarks of Adobe Corporation.

All other brand and product names are trademarks or service marks of their respective owners.

Rev. 3.0

CONTENTS

INTRODUCTION

For Additional Information About Analog Products	1-2
For Technical or Customer Support	1-3
Purpose of This Manual	1-3
Intended Audience	1-4
Manual Contents	1-4
What's New in This Manual	1-6
Related Documents	1-6
Conventions	1-7

LINKER

Overview	2-1
Chapter Outline	2-2
Mapping Files to Memory: the Linker Description File	2-3
Default LDF and Object Code Placement	2-3
Inputs — C, C++ & Assembly Sources	2-4
Outputs — DSP Executables	2-7
The Linking Process and the LDF	2-7
Sample LDF	2-10

CONTENTS

Linker Guide	2-14
Linker Operations	2-14
Describing the Link Target	2-15
Writing a MEMORY{} Command	2-16
A Detailed Memory{} Command	2-16
Placing Code on the Target: the SECTIONS Command	2-23
Using Link Features	2-25
Setting Linker Options	2-26
Interpreting Linker Error and Warning Messages	2-26
Linker Command-Line Reference	2-28
Command-Line Syntax	2-28
Object Files in the Linker Command Line.....	2-28
Switch Format in the Linker Command Line.....	2-29
Filenames on the Linker Command Line.....	2-30
Linker Command-Line Options	2-32
filename	2-35
<null>	2-35
@ file	2-35
-Darchitecture	2-36
-L path.....	2-36
-M	2-36
-MM.....	2-36
-Map file	2-36
-MDmacro[=def]	2-37

-S	2-37
-T file	2-37
-c.....	2-37
-ev	2-37
-es secName	2-38
-help.....	2-38
-i directory.....	2-38
-ip	2-38
-keep symName	2-39
-o filename	2-39
-pp	2-39
-s.....	2-39
-sp	2-39
-t.....	2-39
-v	2-39
-version	2-40
-warnonce.....	2-40
-xref filename.....	2-40
Linker Description File Reference	2-41
LDF Structure	2-42
Command Scoping	2-42
LDF Expressions & Conventions	2-43
Linker Expression Syntax	2-44
Linker Keywords	2-45

CONTENTS

Miscellaneous LDF Keywords	2-47
LDF Operators	2-47
LDF Macros	2-49
LDF Macro List.....	2-50
LDF Macros and Command-Line Interaction.....	2-52
LDF Commands	2-53
ARCHITECTURE()	2-54
DYNAMIC().....	2-54
INCLUDE()	2-55
INPUT_SECTION_ALIGN().....	2-55
LINK_AGAINST()	2-57
MAP().....	2-57
MEMORY{}	2-58
MPMEMORY{}	2-61
OVERLAY_GROUP{}.....	2-62
PACKING()	2-67
PAGE_INPUT()	2-71
PAGE_OUTPUT()	2-72
PLIT{}	2-72
PROCESSOR{}	2-77
SEARCH_DIR()	2-79
SECTIONS{}	2-79
SHARED_MEMORY{}	2-85
LDF Programming Examples	2-88

Linking for Single Processor Memory	2-89
Linking Large Uninitialized Variables	2-90
Linking for Multi-Processor and Shared Memory	2-91
Linking for Overlay Memory	2-96
Using a Procedure Linkage Table	2-100
Using An Overlay Memory Manager	2-104
Managing Overlays	2-106
Managing Two Overlays (Example)	2-112
Reducing Overlay Manager Overhead (Example)	2-118
Linker Glossary	2-123

ARCHIVER

Overview	3-1
Archiver Guide	3-2
Creating an Archive From VisualDSP++	3-2
Filename Conventions.....	3-3
Making Archived Functions Usable	3-3
Writing Archive Routines: Creating Entry Points	3-3
Using Archive Routines	3-4
Archiver Command-Line Reference	3-6
Command-Line Syntax	3-6
Archiver File Search	3-8
Command-Line Reference	3-8
Archiver Glossary	3-10

CONTENTS

ADSP-218X LOADER

Overview	4-1
ADSP-218x Loader Guide	4-2
Working With Different Boot Types	4-2
Bootstrap Loading (Bootng).....	4-3
BDMA - EPROM Bootng	4-4
IDMA - Host Bootng	4-4
Setting Loader Options	4-7
ADSP-218x Loader Command-Line Reference	4-8
Loader Glossary	4-13

ADSP-2191 LOADER

Overview	5-1
Booting in ADSP-2191	5-2
ADSP-2191 Boot Kernel	5-2
Booting Pins - Modes of Operation	5-3
Boot Stream Contents	5-4
Booting from External EPROM or Host	5-4
No-Boot Mode Bootng	5-6
8-bit EPROM Bootng	5-6
UART Bootng	5-7
Serial EPROM Bootng	5-7
ADSP-2191 Boot Loader Utility	5-9
ADSP-2191 Loader Command-Line Reference	5-9

Loader Glossary	5-14
-----------------------	------

ADSP-2192 LOADER

Overview	6-1
ADSP-2192-12 Boot Loader Utility and Run-Time Loader	6-2
Using the Boot Loading Utility	6-3
Running the Boot Loader Utility	6-4
ADSP-2192 Boot Loader Utility Command-Line Reference	6-5
Using the Run-Time Boot Loader	6-10
Run-Time Boot Loader and Overlays Over PCI	6-11
Using OvlPciAdrTbl and OvlMgrTbl Symbols	6-12
Loader Glossary	6-14

SPLITTER

Overview	6-1
Using the Splitter	6-2
Splitter Command-Line Reference	6-3
Splitter Glossary	6-9

FILE FORMATS

Overview	A-1
Source Files	A-2
C/C++ Source Files (.C, .CPP, .CXX)	A-2
Assembly Source Files (.ASM)	A-3
Assembly Initialization Data Files (.DAT)	A-3
Header Files (.H)	A-4

CONTENTS

Linker Description Files (.LDF)	A-4
Linker Command-Line Files (.TXT)	A-4
Build (Processed) Files	A-5
Assembler Object Files (.DOJ)	A-5
Archiver Archive Files (.DLB)	A-5
Linker Executable Files (.DXE, .SM, .OVL, .dlb)	A-5
Linker Memory Map Files (.MAP)	A-6
Debugger Files	A-7
Format References	A-8

UTILITIES

Overview	B-1
Dumper — ELF File Dumper	B-1
Using the Archiver and Dumper For Disassembly	B-3
Dumping Overlay Archive Files	B-4
AEXE2ELF and ELF2AEXE Converters	B-5

LINKER LEGACY SUPPORT

Overview	C-1
Converting from .SYS to .LDF	C-2
C code SEGMENT("...") — LDF SECTIONS{} Conversion ...	C-3
Assembler .SEGMENT — LDF SECTIONS{} Conversion	C-11
SYS .SEGMENT — LDF MEMORY{} Conversion	C-17
Legacy Assembly of Sources with Absolute Placement Directives ..	C-19

INDEX