

VISUALDSP++TM 2.0

Assembler and Preprocessor

Manual for ADSP-218x DSPs

Third Revision, April 2001

Part Number
82-000400-04

Analog Devices, Inc.
Digital Signal Processor Division
One Technology Way
Norwood, Mass. 02062-9106



Copyright Information

©1996–2001 Analog Devices, Inc., ALL RIGHTS RESERVED. This document may not be reproduced in any form without prior, express written consent from Analog Devices, Inc.

Printed in the USA.

Disclaimer

Analog Devices, Inc. reserves the right to change this product without prior notice. Information furnished by Analog Devices is believed to be accurate and reliable. However, no responsibility is assumed by Analog Devices for its use; nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under the patent rights of Analog Devices, Inc.

Trademark and Service Mark Notice

The Analog Devices logo, VisualDSP, SHARC, the SHARC logo, TigerSHARC, the TigerSHARC logo, and EZ-LAB are registered trademarks; VisualDSP++, the VisualDSP++ logo, VDK, Apex-ICE, Mountain-ICE, Summit-ICE, Trek-ICE, and The DSP Collaborative are trademarks of Analog Devices, Inc.

Microsoft and Windows are registered trademarks and Windows NT is a trademark of Microsoft Corporation.

Adobe and Acrobat are registered trademarks of Adobe Corporation.

All other brand and product names are trademarks or service marks of their respective owners.

Rev. 3.0

CONTENTS

INTRODUCTION

For Additional Information About Analog Products	1-2
For Technical or Customer Support	1-2
Purpose of this Manual	1-3
Intended Audience	1-3
Manual Contents Description	1-4
What's New in this Manual	1-5
Related Documents	1-6
Conventions	1-7

ASSEMBLER

Overview	2-1
Assembler Guide	2-3
Writing Assembly Programs	2-3
Program Content	2-6
Program Structure	2-7
Program Interfacing Requirements	2-12
Preprocessing a Program	2-13
Reading a Listing File	2-13

CONTENTS

Setting Assembler Options	2-14
Assembler Command-Line Reference	2-15
Assembler Command-Line Interface	2-16
Assembler Command-Line Options	2-19
Command-Line Reference	2-21
-218{1 3 4 5 6 7 8 9}	2-21
-Ao filename	2-21
-c	2-22
-dmacro[=def]	2-23
-flags-pp -switch [, ...]	2-23
-g	2-23
-h[elp]	2-24
-i directory	2-24
-ip	2-25
-l filename	2-25
-li filename	2-25
-legacy	2-26
-M	2-26
-MM	2-27
-Mo filename	2-27
-Mt filename	2-28
-noip	2-28
-o [filename]	2-28
-pp	2-28

-r	2-29
-sp	2-29
-v[erbose]	2-29
-version	2-29
-w	2-29
Assembler Syntax Reference	2-30
Assembler Keywords and Symbols	2-30
Assembler Expressions	2-35
Assembler and Preprocessor Operators	2-36
Numeric Formats	2-39
Fractional Type Support	2-39
Comment Conventions	2-42
Assembler Directives	2-43
.ALIGN, Specify an Address Alignment	2-47
.EXTERN, Refer to a Globally Available Symbol	2-48
.FILE, Override the Name of an Object File	2-49
.GLOBAL, Make a Symbol Globally Available	2-50
.LEFTMARGIN, Set the Margin Width of a Listing File	2-51
.NEWPAGE, Insert a Page Break in a Listing File	2-52
.PAGELENGTH, Set the Page Length of a Listing File	2-53
.PAGEWIDTH, Set the Page Width of a Listing File	2-54
.PREVIOUS, Revert to the Previously Defined Section	2-55
.SECTION, Declare a Memory Section	2-56
.TYPE, Change Default Symbol Type	2-58

CONTENTS

.VAR, Declare a Data Variable or Buffer	2-59
.VAR/INIT24, Declare a Wide Data Structure	2-63
.WEAK, Support a Weak Symbol Definition and Reference	2-67
Assembler Glossary	2-68

ASSEMBLER ENHANCEMENTS AND LEGACY SUPPORT

Overview	3-1
Command-Line Switches	3-3
New Assembler Switches	3-3
Obsolete and Modified Switches	3-5
Legacy Directives	3-6
.CONST, Declare a Constant	3-8
.DMSEG and .PMSEG, Place Data and Code in Memory Sections	3-9
.ENTRY, Make a Program Label Globally Available	3-11
.EXTERNAL, Refer to a Globally Available Symbol	3-12
.INCLUDE, Include Other Source File	3-13
.INDENT, Indent a Listing File	3-15
.INIT, Initialize a Variable or Buffer	3-16
.INIT and ASCII String Initialization Support	3-18
.LOCAL, Create a Unique Version of the Label	3-19
.MACRO and ENDMACRO, Define a Macro	3-21
.MODULE and .ENDMOD, Declare a Program Module	3-23
.VAR/ABS, Place a Variable at the Specified Address	3-26
Conventions of Syntax	3-27
Modified Assembler and Preprocessor Operators	3-28

Modified Numeric Conventions	3-29
New and Legacy Comment Conventions	3-30
Debugging Capabilities and File Format	3-31
ELF File Format	3-31
Debug Information	3-32

PREPROCESSOR

Overview	4-1
Preprocessor Guide	4-2
Using Header Files	4-3
Writing Macros	4-4
Writing Compound Statements As Macros	4-6
Using Predefined Macros	4-6
Setting Preprocessor Options	4-7
Preprocessor Command-Line Interface	4-8
Preprocessor Switch Description	4-11
Preprocessor Commands and Operators	4-17
#define	4-19
#elif	4-21
#else	4-22
#endif	4-23
#error	4-24
#if	4-25
#ifdef	4-26
#ifndef	4-27

CONTENTS

#include	4-28
#line	4-29
#undef	4-30
#warning	4-30
# (String)	4-31
## (Concatenate)	4-32
? (Generate a Unique Label)	4-33

UTILITIES

Overview	A-1
Comment Converter	A-1

INDEX