I INDEX

Symbols

.DIRECTIVE (see Assembler directives)
? preprocessor operator 3-34

Numerics

Assembler
  command-line switch
    -21 2-21

A

Address alignment 2-39
Address of expression 2-31
address_boundary_expession directive 2-40
ALIGN assembler directive 2-39
Analog product information 1-2
Archiver 2-16
ASCII string initialization support 2-65
Assembler
  command-line switch 2-19
    -D (define macro) 2-21
    -g (generate debug information) 2-21
    -h (-help) 2-21
    -i (include path) 2-22
    -l (listing file) 2-22
    -M (make rule only) 2-23
    -MM (make rule and assemble) 2-24
    -Mo (output make rule) 2-24
    -Mt (make rule for named file) 2-23
    -o (output) 2-24
    -pp (proceed with preprocessing) 2-25
    -r (remove preprocessor information) 2-25
    -sp (skip preprocessing) 2-25
    -v (verbose) 2-25
    -version (display version) 2-26
    -w (skip warning messages) 2-26
command-line syntax 2-16–??, 2-16, ??–2-19
comment conventions 2-36
directives ??–2-66
glossary 2-68
how to use assembler 2-1
keywords 2-27–2-29
listing files (.LST) 2-5, 2-22
numeric formats 2-35
object files (.DOJ) 2-5
operator precedence chart 2-32
options 2-16
overview 2-1

Project Options dialog box 2-16
reference section 2-16–??
reserved keywords 2-30
run-time environment 2-1
source files
(.ASM) 2-4, 2-18
switches 2-19
Assembler interface (see Command-line syntax)
Assembly
expressions 2-31
instructions 2-6
operators 2-32
symbols in source code 2-30
Assembly directive 2-36–2-66
. ALIGN 2-39
.EXTERN 2-42
.FILE 2-43
.GLOBAL 2-44
.LEFTMARGIN 2-45
.LIST 2-46
.LIST_DATFILE 2-47
.LIST_DEFTAB 2-48
.LIST_LOCTAB 2-49
.LIST_WRAPDATA 2-50
.NEWPAGE 2-51
.NOLIST 2-46
.NOLIST_DATFILE 2-47
.NOLIST_WRAPDATA 2-50
.PAGELENGTH 2-52
.PAGEWIDTH 2-53
.PORT 2-54
.PRECISION 2-55
.PREVIOUS 2-56
.ROUND 2-57
.SECTION 2-59
.SEGMENT/.ENDSEG 2-61
.TYPE 2-62
.VAR 2-63
.WEAK 2-67
format 2-6

C

C/C++ and assembly, interfacing 2-10
Changing default symbol type 2-62
Character constant 3-17, 3-25
Commands (see Preprocessor commands)
Comment conventions 2-36
Concatenate (##) preprocessor command 3-33
Constant expression 2-31
Contents
assembly program 2-6
Conventions
address expressions 2-31
assembly directives 2-36
comments 2-36
constant expressions 2-31
file naming 2-17
numeric formats 2-35
-cs! ("!" comment style) preprocessor switch 3-12
-cs/* ("/* */" comment style) preprocessor switch 3-12
-cs// ("//" comment style) preprocessor switch 3-12

-cs{ ("{}" comment style) preprocessor switch 3-12
-csall (all comment styles) preprocessor switch 3-12
Customer support 1-2

D

-D (define macro) assembler switch 2-21
-D (define macro) preprocessor switch 3-12
Declaring variables or buffers 2-63
Default tab width 2-48, 2-49
define (macro or constant) preprocessor command 3-19
DM (data), section and memory type 2-59

E

easm21k assembler 2-16
else (alternate instruction) preprocessor command 3-22
endif (termination) preprocessor command 3-23
error (error message) preprocessor command 3-24
Expressions
  address 2-31
  constant 2-31
EXTERN (global label) assembler directive 2-42

F

FILE (override filename) assembler directive 2-43
File extension
  .ASM (assembly source file) 2-16
  .DAT (data file) 2-16
  .DLB (library file) 2-16
  .DOJ (object file) 2-5, 2-16
  .DXE (executable file) 2-16
  .H (header file) 2-16
  .I (preprocessed file) 3-9
  .IS (preprocessed file) 2-25, 3-1, 3-9
  .LST (listing file) 2-5
File format
  DWARF-2 (Debugging Information Format) 2-16
  ELF (Executable and Linkable Format) 2-16
File naming conventions 2-17
Floating-point
  precision 2-55
  rounding 2-57

G

-g (generate debug information) assembler switch 2-21
Generating unique labels 3-34
GLOBAL (global symbol) assembler directive 2-44

H

-h (help) assembler switch 3-13
Header files 3-4
  system 3-4

user 3-4
-help (display help) assembler switch 2-21

I

-i (include path) assembler switch 2-22
-i (include path) preprocessor switch 3-13
-I directory assembler switch 2-22
if (test if true) preprocessor command 3-25
ifdef (test if defined) preprocessor command 3-26
ifndef (test if not defined) preprocessor command 3-27
include (insert a file) preprocessor command 3-28
Included files
  system header files 3-4
  user header files 3-4
Input section alignment instruction 2-40
INPUT_SECTION_ALIGN() linker instruction 2-40
Inserting a page break 2-51
Instruction set 2-6, 2-68
Interfacing, C/C++ and assembly 2-10

L

-l (listing file) assembler switch 2-22
LDF operator
  INPUT_SECTION_ALIGN() 2-40
LEFTMARGIN assembler directive 2-45
line (output line number) preprocessor command 3-29
Linker 2-16
  Input section alignment instruction 2-40
Linker Description File 2-8, 2-68
LIST assembler directive 2-46
LIST_DATFILE assembler directive 2-47
LIST_LOCTAB assembler directive 2-49
LIST_WRAPDATA assembler directive 2-50
Listing
  data initialization files 2-47
  large opcodes 2-50
Listing file 2-3, 2-12–??
  address 2-12
  line number 2-12
  opcode 2-12
  source code line 2-12
Local tab width 2-48, 2-49

M

-M (make rule only)
  preprocessor switch 3-13
-M (make rule only) assembler switch 2-23
Macros
  compound statements 3-6
  overview 3-5
Macros, predefined 3-7
Manual
  conventions 1-6

new in this edition 1-4
related documents 1-5
Memory sections 2-59
Memory type 2-7
DM (data) 2-59
PM (code and data) 2-59
RAM (random access memory) 2-59
ROM (read only memory) 2-59
-MM (make rule and assemble) preprocessor switch 3-14
-MM (make rule and assemble) assembler switch 2-23
-Mo (output make rule) preprocessor switch 3-15
-Mo (output make rule) assembler switch 2-24
-Mt (output make rule for named file) preprocessor switch 3-15
-Mt assembler switch 2-24

N

Nested include file limitation 3-28
NEWPAGE assembler directive 2-51
NOLIST assembler directive 2-46
NOLIST_WRAPDATA assembler directive 2-50
Notation conventions of this manual 1-6
Numeric formats 2-35

O

-o (output) assembler switch 2-24
-o (output) preprocessor switch 3-15
Object file 2-3

P

-p (proceed with preprocessing only) assembler switch 2-25
PAGELENGTH (page size) assembler directive 2-52
PAGEWIDTH (page width) assembler directive 2-53
PM, section and memory type 2-59
PORT (declare port) assembler legacy directive 2-54
-pp (proceed with preprocessing) assembler switch 2-25
PRECISION assembler directive 2-55
Preprocessor
command format 2-7
command list 3-17
command-line switch
-cs! 3-12
-cs! ("!" comment style) 3-12
-cs/* 3-12
-cs/* ("/* */" comment style) 3-12
-cs// 3-12
-cs// ("//" comment style) 3-12
-cs{ 3-12
-cs{ ("{}" comment style) 3-12
-csall 3-12
-csall (all comment styles) 3-12
-D (define macro) 3-12
-h (help) 3-13
-i (include path) 3-13
-M (make rule only) 3-13
-MM (make rule and assemble) 3-14
-Mo (output make rule) 3-15

-Mt (output make rule for named file) 3-15
-o (output) 3-15
-v (verbose) 3-15
-version (display version) 3-15
directive syntax 3-16
directives 3-16
how to use 3-3
macro definitions 3-6
overview 3-1
preprocessed assembly files 3-1, 3-9
reference section 3-9–3-33
Preprocessor command
(string) 3-32
(concatenate) 3-33
#define 3-19
#elif 3-21
#else 3-22
#endif 3-23
#error 3-24
#if 3-25
#ifdef 3-26
#ifndef 3-27
#include 3-28
#line 3-29
#undef 3-30
#warning 3-31
? (generate unique label) 3-34
Preprocessor switch (see Preprocessor command-line switch)
PREVIOUS assembler directive 2-56
Program 2-6
assembling 2-4
contents 2-6–2-7
interfacing requirements 2-10
preprocessing 2-11
reading a listing file 2-12–??
structure 2-7–2-10
writing an assembly programs 2-3–2-5
Project Options dialog box 2-15, 3-3

R

-r (remove preprocessor info) assembler switch 2-25
-r (remove preprocessor output) assembler switch 2-25
RAM, section and memory type 2-59
Related documents 1-5
ROM, section and memory type 2-59
ROUND (rounding mode) assembler directive 2-57
Rounding modes 2-57

S

SECTION assembler directive 2-59
Section qualifier
DM (data memory) 2-59
PM (code and data) 2-59
RAM (random access memory) 2-59
ROM (read only memory) 2-59
sectionType parameter 2-60
SEGMENT (legacy directive) assembler directive 2-61
Setting
default tab width 2-48
local tab width 2-49
Setting assembler options 2-14

from command line 2-14, 2-19
from VisualDSP++ IDDE 2-1, 2-15
Setting preprocessor options
from command line 3-3
from VisualDSP++ IDDE 3-3
through build tools 3-3
SHARC processors 1-1
-sp (skip preprocessing) assembler switch 2-25
-sp (skip preprocessing) assembler switch 2-25
String (#) preprocessor command 3-32
Switches (see Assembler command line syntax)
Symbols (see Assembly symbols)
Syntax
address expressions 2-31
assembly directives 2-36
compound statement 3-6
constant expressions 2-31
instruction set 2-6
macro 3-5
preprocessor command-line 3-9
preprocessor directive 3-16
System header files 3-4

T

Tab characters 2-48
in source file 2-49
Table 2-7. Numeric Formats 2-35
Technical support 1-2
TYPE assembler directive 2-62

U

undef (undefine) preprocessor command 3-30
unique labels 3-34
User header files 3-4

V

-v (verbose) assembler switch 2-25
-v (verbose) preprocessor switch 3-15
VAR (declare variable) assembler directive 2-63
-verbose assembler switch 2-25
-version (display version) assembler switch 2-26
-version (display version) preprocessor switch 3-15
VisualDSP++
setting assembler options 2-1
setting preprocessor options 3-3

W

-w (disable all warnings) assembler switch 2-26
-w (skip warning messages) assembler switch 2-26
warning (warning message) preprocessor command 3-31
WEAK
assembler directive 2-67
binding 2-67
Wrapping opcode listings 2-50
Writing assembly programs 2-3