VisualDSP++™ 2.0

Linker and Utilities Manual for ADSP-21xxx DSPs

Third Revision, October 2001

Part Number
82-001965-01

Analog Devices, Inc.
Digital Signal Processor Division
One Technology Way
Norwood, Mass. 02062-9106

ANALOG DEVICES

Copyright Information

©2001 Analog Devices, Inc., ALL RIGHTS RESERVED. This document may not be reproduced in any form without prior, express written consent from Analog Devices, Inc.

Printed in the USA.

Disclaimer

Analog Devices, Inc. reserves the right to change this product without prior notice. Information furnished by Analog Devices is believed to be accurate and reliable. However, no responsibility is assumed by Analog Devices for its use; nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under the patent rights of Analog Devices, Inc.

Trademark and Service Mark Notice

The Analog Devices logo, VisualDSP, the VisualDSP logo, SHARC, and the SHARC logo are registered trademarks; VisualDSP++, the VisualDSP++ logo, CROSSCORE, the CROSSCORE logo, EZ-KIT Lite, Apex-ICE, Mountain-ICE, Summit-ICE, Trek-ICE, and The DSP Collaborative are trademarks of Analog Devices, Inc.

Microsoft and Windows are registered trademarks and Windows NT is a trademark of Microsoft Corporation.

Adobe and Acrobat are registered trademarks of Adobe Corporation.

Intel is registered trademark of Intel Corporation.

Motorola is registered trademark of Motorola Corporation.

All other brand and product names are trademarks or service marks of their respective owners.

Rev. 3.0

CONTENTS

INTRODUCTION

For More Information About Analog Products 1-2
For Technical or Customer Support 1-3
Purpose of This Manual 1-3
Intended Audience 1-4
Manual Contents Description 1-4
What's New in This Manual 1-5
Related Documents 1-6
Conventions 1-7

LINKER

Overview 2-1
Mapping Files To Memory with an LDF 2-3
Linking Process Overview 2-3
Default LDF and Object Code Placement 2-3
The Linking Process and the LDF 2-4
Inputs—C, C++ and Assembly Sources 2-9
Input Section Directives in Assembly Code 2-10
Input Section Directives in C/C++ Source Files 2-10

Outputs—DSP Executables 2-12
Linker Guide 2-13
Linker Operations 2-13
Describing the Link Target 2-14
Representing Memory Architecture 2-14
Specifying the Memory Map 2-16
Placing Code on the Target 2-20
Using Linker Features 2-22
Specifying Linker Options 2-23
Linker Error and Warning Messages 2-23
Linker Command-Line Reference 2-25
Command-Line Syntax 2-25
Object Files in the Linker Command Line 2-26
Switch Format in the Linker Command Line 2-27
File Names on the Linker Command Line 2-28
Linker Command-Line Switches 2-30
Linker Description File Reference 2-38
LDF Structure 2-39
Command Scoping 2-39
LDF Expressions and Conventions 2-40
Linker Keywords 2-42
Miscellaneous LDF Keywords 2-44
LDF Operators 2-44
LDF Macros 2-46

LDF Macro List 2-47
LDF Macros and Command-Line Interaction 2-48
LDF Command Summary 2-49
ALIGN() 2-50
ARCHITECTURE() 2-50
ELIMINATE() 2-51
ELIMINATE_SECTIONS() 2-51
INCLUDE() 2-51
INPUT_SECTION_ALIGN() 2-52
KEEP() 2-52
LINK_AGAINST() 2-52
MAP() 2-53
MEMORY{} 2-54
MPMEMORY{} 2-56
OVERLAY_GROUP{} 2-57
PACKING() 2-61
Packing in ADSP-21xxx LDF 2-63
Overlay Packing Formats 2-66
External Execution Packing 2-67
Default Packing - No Reordering 2-68
PLIT{} 2-69
What is a PLIT? 2-69
Allocating Space for PLITs 2-70
PLIT Syntax 2-71

PROCESSOR{} 2-72
RESOLVE() 2-74
SEARCH_DIR() 2-74
SECTIONS{} 2-75
SHARED_MEMORY{} 2-81
LDF Programming Examples 2-84
Linking for Single-Processor Memory 2-85
Linking Large Uninitialized Variables 2-87
Linking for Multi-Processor and Shared Memory 2-88
Using Reflective Semaphores 2-93
Linking for Overlay Memory 2-95
Using a Procedure Linkage Table 2-98
Using An Overlay Memory Manager 2-103
Managing Overlays 2-105
Managing Two Overlays 2-111
Reducing Overlay Manager Overhead 2-118
Linker Glossary 2-122

ARCHIVER

Overview 3-1
Archiver Guide 3-2
Creating Archives in VisualDSP++ Environment 3-2
Archiver Operations 3-3
Filename Conventions 3-3
Making Archived Functions Usable 3-4

Writing Archive Routines: Creating Entry Points 3-4
Using Archive Routines 3-5
Archiver Command-Line Reference 3-6
Archiver Command-Line Syntax 3-6
Archiver File Search 3-8
Archiver Command-Line Switches 3-8
Archiver Glossary 3-10

ADSP-2106X/21160 LOADER

Overview 4-1
Loader Command-Line Reference 4-2
Setting Loader Options 4-2
Running the Loader 4-3
Loader Guide 4-11
Working With Different Boot Types 4-12
Booting 4-12
General Powerup Booting Process (PROM/Link/Host) 4-13
Selecting A Booting Mode 4-14
Boot-Kernel Features and Boot-Loading Process 4-15
Boot-Kernel Changes and Software Issues 4-19
EPROM Booting 4-22
Host Booting 4-27
Link Booting 4-31
Multiprocessor Booting 4-32
Multiprocessor EPROM Booting 4-32

No Boot Mode 4-33
Interrupt Vector Table Location 4-34
Loader Glossary 4-35

ADSP-21161N LOADER

Overview 5-1
Loader Command-Line Reference 5-2
Setting Loader Options 5-2
Running the Loader 5-3
ADSP-21161 Loader Command-Line Switches 5-6
Loader Guide 5-10
Working With Different Boot Types 5-11
Output File Formats 5-11
Selecting A Booting Mode 5-13
ADSP-21161N Boot-Kernels 5-14
Boot-Kernel Changes and Software Issues 5-15
Loader File Header Words 5-18
EPROM Booting 5-19
Host Booting 5-24
Link Port Booting 5-27
SPI Booting 5-30
Multiprocessor Booting 5-32
Multiprocessor EPROM Booting 5-32
Supporting the Include Format for PROM Booting 5-33

Loader Glossary 5-35

SPLITTER

Overview 6-1
Splitter Guide 6-2
Setting Splitter Options 6-2
Splitter Command-Line Reference 6-3
Splitter Glossary 6-9

FILE FORMATS

Overview A-1
Source Files A-2
C/C++ Source Files A-2
Assembly Source Files (.ASM) A-3
Assembly Initialization Data Files (.DAT) A-3
Header Files (.H) A-5
Linker Description Files (.LDF) A-6
Linker Command-Line Files (.TXT) A-6
Build (Processed) Files A-7
Assembler Object Files (.DOJ) A-7
Archiver Archive Files (.DLB) A-8
Linker Executable Files (.DXE, .SM, .OVL, .DLO) A-8
Linker Memory Map Files (.MAP) A-8
Loader Hex Format Files (.LDR) A-9
Loader ASCII Format Files (.LDR) A-10

Loader Include Format Files (.LDR) A-10
Loader Binary Format Files (.LDR) A-11
Splitter Motorola S-Record Format Files (.S_#) A-11
Splitter Hex Format Files (.H_#) A-13
Splitter Byte-Stacked Format Files (.STK) A-13
Debugger Files A-15
Format References A-17

UTILITIES

Overview B-1
Dumper — ELF File Dumper B-1
Using the Archiver and Dumper For Disassembly B-3
Dumping Overlay Archive Files B-4
Mem21k — Memory Initializer B-5

LINKER LEGACY SUPPORT

INDEX