


NOTES:

1. POPULATE M1-M5 WITH RUBBER FEET. SEE SHEET 2 FOR LOCATION.
2. PLACE SERIAL NUMBER ON BOTTOM SIDE SEE SHEET 2 FOR LOCATION.
3. PLACE BOM REV ON BOTTOM SIDE SEE SHEET 2 FOR LOCATION.
4. BEFORE WAVE SOLDERING MASK HOLES FOR TP1-TP7, P7, P8 & ZP2.
5. BREAK OFF STRIPS AT COMPLETION OF ASSEMBLY.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE : .XX +/- .010 .XXX +/- .005	CONTRACT NO.		 20 Cotton Road Nashua, New Hampshire 03063 (603) 883-2430 FAX (603) 882-2655
	APPROVALS	DATE	
MATERIAL	DRAWN	06/25/07	ASSEMBLY DRAWING TOP SIDE ADSP-21364 EZ-KIT LITE
FINISH	CHECKED		
	ENGINEERING		SIZE B DWG. NO. ASSMAA0190-2004-REF
	QUALITY		
DO NOT SCALE THIS DRAWING	MANUFACTURING		SCALE 1 : 1
		SHEET 1 OF 2	REV. 2.0